

# Gigaset

## CL660 HX

Detailed information on the telephone system:

- User guide of your Gigaset telephone  
[www.gigaset.com/manuals](http://www.gigaset.com/manuals)



- Documentation relating to your base/router

User guide online on your  
smartphone or tablet:

Download the Gigaset Help app





## Gigaset HX – the universal handset

With your Gigaset HX handset, you have purchased a high-quality, multifunctional and future-proof device.

You can use your handset with several different DECT bases.

### On a Gigaset base

Connect your HX handset to a Gigaset base and use the many features with the quality you would expect from Gigaset.

If your Gigaset base is IP-compatible, you can also make broadband calls using your HX handset with the highest voice quality (HDSP).

In this guide, all functions that are available for your HX handset are detailed/described. The complete functionality with Gigaset bases is described in the guide relevant to your Gigaset system.

All Gigaset user guides can be found at ➔ [www.gigaset.com/manuals](http://www.gigaset.com/manuals)

or online on your smartphone or tablet:

➔ download the Gigaset Help app from or

### On a DECT/GAP telephone or router from another manufacturer

The handset also functions with DECT/GAP telephones from other manufacturers, of course, as well as DECT routers. Additional information can be found at

➔ [www.gigaset.com/compatibility](http://www.gigaset.com/compatibility).

### On DECT routers with CAT-iq 2.0

Your Gigaset HX handset is certified in accordance with the DECT/CAT-iq 2.0 standard. As a result, operation with a DECT router with CAT-iq functionality is possible.

Handset functions on a CAT-iq router (amongst others):

- full access to the central directory on the router as well as the local directory integrated in the handset,
- convenient calling and using of call lists,
- using several lines and call numbers <sup>\*)</sup>,
- enjoy broadband calls in guaranteed/certified HD-Voice <sup>TM</sup> quality.

➔ Details can be found in the relevant user guide for your router.


Additional information regarding your HX handset can be found at ➔ [www.gigaset.com/hx](http://www.gigaset.com/hx)

Details regarding the functionality of the handset on various bases and routers can be found at

➔ [www.gigaset.com/compatibility](http://www.gigaset.com/compatibility)

\*) The relevant scope of the function is dependent on the country, network and router

# Overview



# Contents

Overview .....	3
Safety precautions .....	6
Getting started .....	7
Using the telephone .....	12
Getting to know your telephone .....	12
Making calls .....	16
Local answer machine .....	19
Local handset directory .....	20
Message lists .....	24
Call lists .....	25
Additional functions .....	26
Calendar .....	27
Alarm clock .....	29
Baby monitor .....	30
Protection against unwanted calls .....	32
Resource Directory .....	34
Additional functions using the PC interface .....	35
Setting the handset .....	37
Appendix .....	45
Service (Customer Care) .....	45
Manufacturer's advice .....	45
Technical data .....	47
Display icons .....	49
Index .....	51



Not all functions described in the user guide are available in all countries or from all network providers.

---

## Additional information

Regarding the telephone system, if the handset is connected to a Gigaset base:

- User guide for your Gigaset telephone

Regarding the telephone system, if the handset is connected to another base/router:

- Documentation regarding your base/your router



You can obtain all Gigaset user guides



- in PDF format: → [www.gigaset.com/manuals](http://www.gigaset.com/manuals)
- online: → **Gigaset Help** app for your smartphone or tablet



## Illustration in the user guide

	Warnings, which, if not heeded, can result in injury to persons or damage to devices.
	Important information regarding function and appropriate handling or functions that could generate costs.
	Prerequisite for being able to carry out the following action.
	Additional helpful information.

## Keys

 or 	Talk key	 or 	Handsfree key
	End call key	 0 to 9	Number / letter keys
	Control key rim / centre		Message key
	Recall key		Star key
	Hash key		
OK, Back, Select, Change, Save, ...		Display keys	

## Procedures

Example: Switching Auto answer on/off

- ▶  ... use  to select  **Settings** ▶ **OK** ▶  **Telephony** ▶ **OK** ▶ **Auto Answer** ▶ **Change** ( = on)

Step	Follow this procedure
▶ 	When in idle status press the <b>centre</b> of the control key. The main menu opens.
▶  	Navigate to the  icon using the control key  .
▶ <b>OK</b>	Select <b>OK</b> to confirm. The submenu <b>Settings</b> opens.
▶  <b>Telephony</b>	Select the <b>Telephony</b> entry using the control key  .
▶ <b>OK</b>	Select <b>OK</b> to confirm. The submenu <b>Telephony</b> opens.
▶ <b>Auto Answer</b>	The function to switch Auto answer on/off appears as the first menu item.
▶ <b>Change</b>	Select <b>Change</b> to activate or deactivate. Function is activated <input checked="" type="checkbox"/> / deactivated <input type="checkbox"/> .

## Safety precautions



Read the safety precautions and the user guide before use.

The device cannot be used in the event of a power failure. In case of a power failure it is also **not** possible to make **emergency calls**.

Emergency numbers **cannot** be dialled if the **keypad/display lock** is activated!

	Do not use the devices in environments with a potential explosion hazard (e.g. paint shops).
	The devices are not splashproof. For this reason do not install them in a damp environment such as bathrooms or shower rooms.
	Use only the power adapter indicated on the device. Whilst charging, the power socket must be easily accessible.
	Use only <b>rechargeable batteries</b> that correspond to the <b>specification</b> (see "Specifications"). Never use a conventional (non-rechargeable) battery or other battery types as this could result in significant health risks and personal injury. Rechargeable batteries, which are noticeably damaged, must be replaced.
	Remove faulty devices from use or have them repaired by our Service team, as these could interfere with other wireless services.
	Do not use the device if the display is cracked or broken. Broken glass or plastic can cause injury to hands and face. Send the device to our Service department to be repaired.
	Do not hold the rear of the handset to your ear when it is ringing or when speaker mode is activated. Otherwise you risk serious and permanent damage to your hearing. The phone may cause interference in analogue hearing aids (humming or whistling) or cause them to overload. If you require assistance, please contact the hearing aid supplier.
	Using your telephone may affect nearby medical equipment. Be aware of the technical conditions in your particular environment, e.g. doctor's surgery. If you use a medical device (e.g. a pacemaker), please contact the device manufacturer. They will be able to advise you regarding the susceptibility of the device to external sources of high frequency energy (for the specifications of your Gigaset product see "Specifications").

# Getting started

## Contents of the package

- One handset
- One battery cover (rear cover for the handset)
- Two batteries
- One charging cradle incl. power adapter
- One user guide



The charging cradle is designed for use in enclosed, dry rooms within a temperature range of +5 °C to +45 °C.

The device's feet do not usually leave any marks on surfaces. However, due to the multitude of different varnishes and polishes used on furniture, contact marks on the surfaces cannot be completely ruled out.

Never expose the telephone to heat sources, direct sunlight or other electrical devices.


Protect your telephone from moisture, dust, corrosive liquids and vapours.

## Connecting the charging cradle

- ▶ Connect the flat plug of the power adapter **1**.
- ▶ Plug the mains unit into your power socket **2**.

To remove the plug from the charging cradle again:

- ▶ Disconnect the power adapter from the mains power supply.
- ▶ Press the release button **3**.
- ▶ Pull out the plug **4**.



## Setting up the handset for use

The display is protected by a plastic film. ▶ Please remove the protective film!

### Inserting the batteries



Only use rechargeable batteries, as this could otherwise result in significant health risks and personal injury. For example, the outer casing of the batteries could be destroyed or the batteries could explode. The device could also malfunction or be damaged as a result of using batteries that are not of the recommended type.




- ▶ Insert the batteries (for correct +/- direction, see diagram).
- ▶ Fit the battery cover from the top.
- ▶ Press the cover until it clicks into place.
- ▶ To re-open the battery cover:
  - ▶ Insert a fingernail into the notch at the top of the cover and slide it downwards.

### Charging the batteries

- ▶ Charge the batteries fully prior to first use in the charging cradle or using a standard USB mains adapter.

The batteries are fully charged when the power icon  disappears from the display.



Batteries may heat up during charging. This is not dangerous.

After a time, the charging capacity of the batteries will decrease for technical reasons.

## Changing the display language

You can change the display language, if the telephone has been set to an incomprehensible language.

- ▶ Press the centre of the control key 
- ▶ Press the keys **9** and **5** **slowly** and successively ... the language settings display appears, the set language (e. g. **English**) is highlighted ( = selected).
- ▶ To select a different language: ▶ Press the control key  until the desired language is highlighted on the display, e. g. **Francais** ▶ press the key on the right directly underneath the display to activate the language.
- ▶ To revert to idle status: ▶ Press and **hold** the End call key 

Deutsch	
English	
Francais	

## Registering the handset (depending on the base)



Registration must be initiated on the base station **and** on the handset.

Both must be carried out **within 60 secs.**

### On the base / router

- |                             |  |
|-----------------------------|--|
| Gigaset base:               | ▶ Press and <b>hold</b> the Registration/Paging key on the base station (approx. 3 sec.).          |
| Other base station/ router: | ▶ Information regarding the registration procedure → Documentation regarding your base/your router |

### On the handset

- ▶  ▶ ... use  to select  **Settings** ▶ **OK** ▶  **Registration** ▶ **OK** ▶ **Register Handset** ▶ **OK** ... an available base is sought ▶ ... if required: enter system PIN (default setting on Gigaset bases: **0000**) ▶ **OK**

Once registration is complete, the handset returns to idle status. The internal number of the handset appears in the display, e.g. **INT 1**. If not, repeat the procedure.

A handset can be registered to up to four base stations.

- |   |  |
|---|--|
| Change of base:                                     | ▶ <b>Select Base</b> ▶ <b>OK</b> ▶ ... use  to select base or <b>Best Base</b> ▶ <b>Select</b> (  = selected)<br><b>Best Base:</b> The handset chooses the base station with the best reception as soon as it loses connection to the current base station.                      |
| De-registering the handset (depending on the base): | ▶ <b>De-register Handset</b> ▶ <b>OK</b> ... the handset being used is selected ▶ ... use  to select another handset if required ▶ <b>OK</b> ... enter system PIN if required ▶ <b>OK</b> ▶ ... Confirm de-registration with <b>Yes</b><br>If the handset is still registered to other bases, it switches to the base with the best reception ( <b>Best Base</b> ). |

### Setting the date and time

Set the date/time so that the correct date and time can be assigned to incoming calls, and to enable the alarm to be used.




Date and time are set using the base. The date and time can also be set on an IP-compatible base via a time server on the network.

If the base permits it, you can set the date and time manually using the handset.

- ▶ Press the display key **Time**

or, if the date and time have already been set:

- ▶ ▶ ... use to select **Settings** ▶ **OK** ▶ **Date/Time** ▶ **OK**




The active cursor position flashes ▶ ... change cursor position with ▶ ... switch between cursor positions with

Enter date:

- ▶ ... using enter the day, month and year in 8-digit format,  
e.g. for 15/08/2016.

Enter time:

- ▶ ... using enter hours and minutes in 4-digit format,  
e.g. for 07:15.



Save settings:

- ▶ Press the display key **Save**. ... **Saved** is shown in the display and a confirmation tone sounds.

Return to idle status:

- ▶ Press and **hold** the End call key

**The telephone is now ready for use.**

## Connecting the headset

- ▶ Remove cover from the left side of the handset.
- ▶ Connect headset with 2.5 mm headphone jack **1**.
- ▶ Replace cover after use.

The headset volume corresponds to the setting for the receiver volume.



## Connecting the USB data cable

For data exchange between the handset and PC:

- ▶ Connect the USB data cable with micro-USB plug into the USB socket at the bottom of the handset **1**.



Connect the handset **directly** to the PC, **not** via a USB hub.



# Using the telephone

## Getting to know your telephone

### Switch the handset on/off

- Switch on: ► When the handset is switched off, press and **hold** the End call key 
- Switch off: ► When the handset is in idle status, press and **hold** the End call key 

### Lock/unlock the keypad

The keypad lock prevents any accidental use of the telephone.

Lock/unlock the keypad: ►  Press and **hold**

Keypad lock activated: the following symbol appears 

 If a call is indicated on the handset, the keypad automatically unlocks and you can accept the call. It then locks again when the call is finished.

It is not possible to call emergency numbers either when keypad lock is activated.

### Control key



The control key enables you to navigate the menus and input fields, and also to call up certain functions depending on the situation.

In the description below, the side of the control key (up, down, right, left) that you have to press in the different operating situations is marked in black, e. g.  for "press right on the control key" or  for "press the centre of the control key".

#### In idle status

Open the directory

 Press **briefly**

Open the list of available online directories (Gigaset GO-Box 100) or central directory of the base (e.g. CAT-iq base)

 Press and **hold**

Open the main menu

 or 

Open the list of handsets

#### In submenus, selection and entry fields

Confirm a function



## During a conversation

Open the directory



Press and hold

Open the list of available online directories (Gigaset GO-Box 100) or central directory of the base (e.g. CAT-iq base)



Mute the microphone



Initiate an internal consultation call




Adjust the loudspeaker volume for receiver and handsfree mode



## Display keys

The display keys perform a range of functions depending on the operating situation.



Display key icons → p. 49.

## Menu guidance

The functions of your telephone are displayed in a menu that consists of several levels.



The menu guidance depends on the base. Depending on the number and type of available functions, these may be provided in different menus, e.g. at top level or in a submenu.

Examples: **Audio Settings** may be in the top-level menu or in the **Settings** submenu, while **Calendar** may be in the **Organizer** menu or the **Additional Features** menu.

## Selecting/confirming functions

Confirm selection using

OK or press the centre of the control key

One menu level back using

Back

Press and hold

Change to idle status

Change on / off

Switch function on/off using

Select activated / not activated

Activate/deactivate option using


## Getting to know your telephone

### Main menu

In idle status: ▶ Press the **centre** of the control key  ▶ ... use the control key  to select a submenu ▶ **OK**

The main menu functions are shown in the display as icons. The icon for the selected function is highlighted in colour and the name of the associated function appears in the display header.

Example



### Submenus

The functions in the submenus are displayed as lists.

To access a function: ▶ ... use the control key  to select a function ▶ **OK**


Return to the previous menu level:

- ▶ Press the display key **Back**
- or
- ▶ Press the End call key  **briefly**

### Returning to idle status

- ▶ Press and **hold** the End call key 

Example



If a key is not pressed, after 2 minutes the display will **automatically** change to idle status.

## Entering text

### Input position

- ▶ Use  to select an entry field. A field is activated when the cursor is blinking inside it.
- ▶ Use  to move the position of the cursor.

### Correcting incorrect entries

- Delete **characters** to the left of the cursor: ▶  Press **briefly**
- Delete **words** to the left of the cursor: ▶  Press and **hold**

### Entering letters/characters

Multiple letters and numbers are assigned to each key between **2** and **9** and the **0** key. As soon as a key is pressed, the possible characters are displayed at the bottom of the display. The selected character is highlighted.

New Entry	
First Name:	Peter
Surname:	
Phone (Home):	
 	Abc
	

- Selecting letters/numbers: ▶ Press the key **briefly** several times in succession
- Switch between lower case, upper case and number entry mode: ▶ Press the hash key  When editing a directory entry, the first letter and each letter following a space is automatically in upper case.
- Entering special characters: ▶ Press the star key  ▶ ... use  to navigate to the desired character ▶ **Insert**



The availability of special characters depends on the character set of the handset.

## Making calls

---

### Making a call

- ▶ ... use  to enter the number ▶ briefly press the Talk key 
  - or
  - ▶ press and hold the Talk key  ▶ ... use  to enter the number
- Cancel dialling: ▶ Press the End call key 

### On a Gigaset GO-Box 100 or another IP-compatible Gigaset base

The connection is selected by the send connection (line) set for the handset. To use another line:

- ▶ press and hold the Talk key  ▶ ... use  to select the line ▶ Dial ▶
- ... use  to enter the number ... the number is dialled approximately 3 seconds after the last digit is entered

---

### Dialling a number from the local directory

- ▶ ... use  to open the directory ▶ ... use  to select an entry ▶ press the Talk key 

If multiple numbers are entered:

- ▶ ... use  to select the number ▶ press the Talk key  ... the number is dialled



For fast access (quick dial): Assign numbers from the directory to the digit or display keys.

---

### Dialling from a public/central directory

Depending on the base to which the handset is connected to, you can dial from a public directory, the Gigaset.net directory (e.g. Gigaset GO-Box 100) or a central directory on a CAT-iq base.

- ▶ press and hold 

Further information → in the detailed user guide for your telephone

---

### Dialling from the redial list

The redial list contains the 20 numbers last dialled with the handset.

- ▶ Briefly press the Talk key  ... the redial list opens ▶ ... use  to select an entry ▶ press the Talk key 

If a name is displayed:

- ▶ View ... the number is displayed ▶ ... use  to browse numbers if necessary ▶ ... when the required number is reached press the Talk key 

## Managing entries in the redial list

- ▶ Briefly press the Talk key  ... the redial list opens ▶ ... use  to select an entry ▶ Options ... possible options:
  - Copy an entry to the directory: ▶  Copy to Directory ▶ OK
  - Copy the number to the display:
    - ▶  Display number ▶ OK ▶ ... use  to edit or add numbers if necessary ... use  to save as a new entry in the directory
  - Delete the selected entry: ▶  Delete entry ▶ OK
  - Delete all entries: ▶  Delete List ▶ OK

## Dialling from the call list

The call lists (→ p. 25) contain the most recent accepted, outgoing and missed calls.

- ▶  ▶ ... use  to select  Call Lists ▶ OK ▶ ... use  to select a list ▶ OK ▶ ... use  to select an entry ▶ press the Talk key 

Example

All calls	
 	Frank
	14/02/2016, 15:40
 	089563795
	13/02/2016, 15:32
 	Susan Black
	11/02/2016, 13:20
 View	 Options



The call lists can be displayed directly by pressing the display key **Calls** if the relevant function has been assigned to the display key.

The **Missed calls** list can also be opened by pressing the Message key .

## Incoming calls

An incoming call is indicated by ringing, by a display on the screen and by the flashing Talk key . Accepting a call:

- Press the Talk key 
- If **Auto Answer** is activated: ▶ Remove the handset from the charging cradle
- Forward to the answer machine: ▶ 
- Accept a call on the headset

Switch off ringtone: ▶ **Silence** ... the call can be accepted for as long as it is shown on the display

### During a conversation

---

#### Handsfree mode

Activating/deactivating handsfree mode during a call, when establishing a connection and when listening to the answer machine:

- ▶ Press the handsfree key 

Placing the handset in the charging cradle during a call:

- ▶ Press and hold down the handsfree key  ▶ ... Place the handset in the charging cradle ▶ ... hold  for a further 2 seconds

---

#### Call volume

Applies to the current mode (handsfree, receiver or headset):

- ▶ Press  ▶ ... use  to set the volume ▶ **Save**



The setting is automatically saved after around 3 seconds, even if **Save** is not pressed.

---

#### Muting the microphone

When the microphone is switched off, callers will no longer hear you.

Switch the microphone on/off during a call: ▶ Press .

## Local answer machine

(only on Gigaset bases with local answer machine)

### Switching the answer machine on/off:

- ▶  ... use  to select  Answer Machine ▶ OK ▶  Activation ▶ OK ▶ ... use  to select an answer machine (if there are several) ▶ Change ▶ ... use  to select On or Off ▶ Save

### Playing back messages:

- ▶ Press the Message key  ▶ ... use  to select an answer machine (if there are messages for several answer machines) ▶ OK

### Recording a personal announcement/advisory message:

- ▶  ... use  to select  Answer Machine ▶ OK ▶  Announcements ▶ OK ▶ ... use  to select Record Announcem. or Rec. Advisory Msg. ▶ OK ▶ ... use  to select an answer machine (if there are several) ▶ OK ▶ OK ▶ ... record an announcement (at least 3 seconds) ... possible options

Complete the recording and save:

- ▶ End ... the announcement is played back for you to check

Cancel the recording: ▶ Press the End call key  or Back

Resume the recording: ▶ OK

Repeat the recording: ▶ New

## Local handset directory

The local directory is unique to the handset. However, it is possible to send entries to other handsets (→ p. 23).



Information about online directories (e.g. on a Gigaset GO-Box 100) or central directories on CAT-iq bases → user guide of the base.

### Opening the directory

- ▶ Briefly press in idle status

### Directory entries

Number of entries: up to 400

Information: First name and surname, up to three telephone numbers, e-mail address, anniversary with alert, VIP ringtone with VIP icon, CLIP-picture

Length of the entries: Numbers: max. 32 digits  
First name, surname: max. 16 characters  
E-mail address: max. 64 characters

### Creating an entry

- ▶ <New Entry> ▶ OK ▶ ... use to switch between the entry fields and enter data for an entry:.

Names/numbers:

- ▶ ... use to enter first names and/or surnames, at least one number (personal, office, or mobile) and an e-mail address, if applicable

Anniversary:

- ▶ ... use to activate/deactivate Anniversary ▶ ... use to enter date and time ▶ ... use to select type of alert (Visual only or a ringtone)

Caller Melody (VIP):

- ▶ ... use to select the ringtone that will indicate a call from the participant ... if a Caller Melody (VIP) has been assigned, the entry will appear in the directory with the icon.

Save entry: ▶ Save

Example

New Entry	
First Name:	
Robert	
Surname:	
I	
Phone (Home):	
Abc	▼
◀ C	Save



The entry is only valid if it contains at least one number.

## Searching for/selecting a directory entry

- ▶  ▶ ... use  to browse searched names
- or
- ▶  ▶ ... use  to enter initial letters (max. 8 letters) ... the display jumps to the first name starting with these initial letters ▶ ... use  to continue browsing to the desired entry, if needed

Scroll through directory: ▶  ▶ Press and hold 

## Displaying/changing an entry

- ▶  ▶ ... use  to select entry ▶ View ▶ ... use  to select the field to be changed ▶ Edit
- or
- ▶  ▶ ... use  to select an entry ▶ Options ▶ Edit entry ▶ OK

## Deleting entries

Delete the selected entry: ▶  ▶ ... use  to select an entry ▶ Options ▶  Delete entry ▶ OK

Delete all entries: ▶  ▶ Options ▶  Delete all ▶ OK ▶ Yes

## Setting the order of the directory entries

Directory entries can be sorted by first name or surname.

- ▶  ▶ Options ▶  Sort by Surname / Sort by First Name

If no name was entered, the default telephone number is shown in the surname field. These entries appear at the beginning of the list, regardless of how the entries are sorted.

The sort order is as follows:

Space | Digits (0-9) | Letters (alphabetically) | Other characters.

## Displaying the number of entries available in the directory

- ▶  ▶ Options ▶  Available Memory ▶ OK

## Copying number to the directory

Copy numbers to the directory:

- From a list e.g. the call list or the redial list
- When dialling a number

The number is displayed or highlighted.

► Press the display key  or Options ►  Copy to Directory ► OK ... possible options:  
Create a new entry:

► <New Entry> ► OK ► ... use  to select number type ► OK ► complete entry ► Save

Add number to an existing entry:

► ... use  to select an entry ► OK ► ... use  to select number type ► OK ... the number is entered or a prompt to overwrite an existing number is displayed ► ... if required, answer the prompt with Yes/No ► Save

## Copying an entry/directory



The sending and receiving handset must both be registered to the same base station.  
The other handset and the base station are able to send and receive directory entries.



An external call interrupts the transfer.

Caller pictures and sounds are not transferred. Only the date is transferred for an anniversary.

**Both handsets support vCards:**

- No entry with the name is available: a new entry is created.
- An entry with the name is already available: The entry is expanded to include the new numbers. If the entry contains more numbers than allowed by the recipient handset, a second entry is created with the same name.

**The recipient handset does not support vCards:**

A separate entry is created and sent for each number.

**The sending handset does not support vCards:**

A new entry is created on the receiving handset and the transferred number is added to the **Phone (Home)** field. If an entry with this number already exists, the copied number is discarded.

## Copying individual entries

► ► ... use to select the desired entry ► Options ► Copy Entry ► OK ► to Internal ► OK ► ... use to select the receiving handset ► OK ... the entry is copied

Copy the next entry after successful transfer: ► Press Yes or No

## Copying the entire directory

► ► Options ► Copy All ► OK ► to Internal ► OK ► ... use to select the receiving handset ► OK ... the entries are copied one after the other

## Synchronising the phonebook with the PC address book (Gigaset QuickSync)



The Gigaset QuickSync programme has been installed on the computer.

The handset is connected via a USB data cable to the computer.

Free download and further information at ► [www.gigaset.com/quicksync](http://www.gigaset.com/quicksync)

## Message lists

Notifications about missed calls, messages on the answer machine/network mailbox and missed alarms are saved in the messages list.


As soon as a **new message** arrives, an advisory tone will sound. The Message key  also flashes (if activated). Activation from the handset is only possible on Gigaset bases. Use the web interface as required for CAT-iq routers. Information → user guide of the base/router.

Icons for message types and the number of new messages are shown on the idle display.

Notification for the following message types is available:

-  on the answer machine/network mailbox
-  in the missed calls list
-  in the missed alarms list

Example




 The icon for the network mailbox is always displayed, provided the number is stored in the telephone. The other lists are only displayed if they contain messages.

Display messages:

- ▶ Press the Message key  ... Messages lists that contain messages are displayed, **Mailbox:** is always displayed
- An entry is marked in **bold:** new messages are available. The number of new messages is shown in brackets.
- An entry is **not** marked in bold: no new messages. The number of old messages is shown in brackets.
- ▶ ... use  to select a list ▶ **OK** ... the calls or messages are listed

Network mailbox: The network mailbox number is dialled.

Example



 The message list contains an entry for every answer machine assigned to the handset, e.g. for the local answer machine on a Gigaset base / CAT-iq router or for a network mailbox.

# Call lists

The telephone saves different types of calls (missed, accepted and outgoing calls) in lists.



The base/router to which the handset is registered provides information on call numbers.

Detailed information can be found at → [www.gigaset.com/compatibility](http://www.gigaset.com/compatibility).

## List entry

The following information is displayed in the list entries:

- The list type (in the header)
- Icon for the type of entry:
  - Missed calls,
  - Accepted calls,
  - Outgoing calls,
  - Call on the answer machine
- Caller's number. If the number is stored in the directory, the name and number type (Phone (Home), Phone (Office), Phone (Mobile)) are shown instead. In the event of missed calls, the number of missed calls from this number is also shown in square brackets.
- Connection by which the call was received/made
- Date and time of call (if set)

## Example

All calls	
	Frank
	Today, 15:40 [3]
	089563795
	13/05/2016, 18:32
	Susan Black
	12/05/2016, 13:12
View	Options

## Opening the call list

Via the display key: ► Calls ► ... use to select the list ► OK

Via the menu: ► ► ... use to select Call Lists ► OK ► ... use to select the list ► OK

Via the Message key (missed calls):

► Press the Message key ► Missed Calls: ► OK

## Calling back a caller from the call list

► ► ... use to select Call Lists ► OK ► ... use to select list ► OK ► ... use to select entry ► Press the Talk key

## Additional options

► ► ... use to select Call Lists ► OK ► ... use to select list ► OK ... possible options:

View an entry: ► ... use to select entry ► View

Copy the number to the directory:

► ... use to select entry ► Options ► Copy to Directory

Delete an entry: ► ... use to select entry ► Options ► Delete entry ► OK

Delete list: ► Options ► Delete List ► OK ► Yes

# Additional functions



The functions actually available on your telephone and how they are operated depends on the base/router to which the handset is registered.

The following description applies to a Gigaset GO-Box 100. The procedure required for your telephone may differ from the procedures described here.



## Additional information

Regarding the telephone system, if the handset is connected to a Gigaset base:

→ User guide for your Gigaset telephone

Regarding the telephone system, if the handset is connected to another base/router:

→ Documentation regarding your base/your router

You can obtain all Gigaset user guides

in PDF format: → [www.gigaset.com/manuals](http://www.gigaset.com/manuals)

online: → Gigaset Help app for your smartphone or tablet



# Calendar

You can remind yourself of up to **30 appointments**.

In the calendar, the current day is outlined in white; on days with appointments, the numbers are displayed in colour. When a day is selected, it will be outlined in colour.

July 2016						
Mo	Tu	We	Th	Fr	Sa	Su
01	02	03				
04	05	06	07	08	09	10
11	12	13	14	15	16	17
18	19	20	21	22	23	24
25	26	27	28	29	30	31

Back OK

## Saving appointments to the calendar



Date and time have been set.

- ▶ ... use to select ► OK ► ► OK ► ... use to select desired day ► OK ... then
  - Switch on/off: Activation: ... use to select On or Off
  - Enter date: Date ... the selected day has been pre-set ► ... use to enter new date
  - Enter time: Time ► ... use to enter hours and minutes of the appointment
  - Set name: Text ► ... use to enter a description of the appointment (e.g. evening meal, meeting)
  - Set alarm tone: Signal ► ... use to select the melody of the reminder alarm or deactivate the acoustic signal
- Enter information for the appointment:
  - ... use to successively select Date, Time, Text and Signal ► ... use or to set the relevant value ► Save
- Save appointment: Save



If an appointment has already been entered: ► <New Entry> ► OK ► ... Then enter information for the appointment.

## Notification of appointments/anniversaries

Anniversaries are transferred from the directory and displayed as an appointment. An appointment/anniversary is displayed in idle status and the selected ringtone plays for 60 seconds as a notification.

- Acknowledge and stop the reminder: ► Press the display key OFF



During a call, a reminder is indicated on the handset **once** with an advisory tone on the handset.

### Displaying missed appointments/anniversaries

The following appointments and anniversaries are saved in the **Missed Alarms** list:

- The appointment/anniversary call was not acknowledged.
- The appointment/anniversary was notified during a phone call.
- The handset was switched off at the time of the appointment/anniversary.

The last 10 entries are stored. The icon and the number of new entries are shown in the display. The most recent entry appears at the top of the list.

#### Opening the list

- Press the Message key ► **Missed Alarms:** ► **OK** ► ... use to browse through the list of any appointments
- or
- ► ... use to select **Organizer** ► **OK** ► **Missed Alarms** ► **OK**

Each entry is displayed with the number or name, date and time. The most recent entry appears at the top of the list.

- Delete an appointment/anniversary: ► **Delete**

### Displaying/changing/deleting stored appointments

- ► ... use to select **Organizer** ► **OK** ► **Calendar** ► **OK** ► ... use to select day ► **OK** ... the appointment list is displayed ► ... use to select date ... possible options:

Display appointment details:

- **View** ... The appointment settings are displayed

Change appointment: ► **View** ► **Edit**

- or ► **Options** ► **Edit entry** ► **OK**

Activate/deactivate appointment:

- **Options** ► **Activate/Deactivate** ► **OK**

Delete appointment: ► **Options** ► **Delete entry** ► **OK**

Delete all appointments for a day:

- **Options** ► **Delete all Appoints.** ► **OK** ► **Yes**

## Alarm clock



Date and time have been set.

### Activating/deactivating the alarm clock and setting the wake-up time

► ... use to select Organizer ► OK ► Alarm Clock ► OK ... then

Switch on/off: ► Activation: ... use to select On or Off

Setting the wake-up time:

► Time ► ... use to enter hours and minutes

Set days: ► Occurrence ► ... use to switch between Monday-Friday and Daily

Set the volume: ► Volume ► ... use to set volume in 5 increments or select crescendo (increasing volume)

Set alarm: ► Melody ► ... use to select a ringtone for the alarm

Enter alarm data: ► ... use to successively select Time, Occurrence, Volume and Melody ► ... use or to set the relevant value ► Save

Save settings: ► Save

When the alarm clock is activated, the icon and the wake-up time are displayed in idle display.

### Alarm

An alarm is shown on the display and indicated by the selected ringtone melody. The alarm sounds for 60 seconds. If no key is pressed, the alarm is repeated after 5 minutes. After the second repetition, the alarm call is deactivated for 24 hours.



During a call, the alarm is only indicated by a short tone.

### Switching off /repeating the alarm after an interval (snooze mode)

Deactivate the alarm: ► OFF

Repeat the alarm (snooze mode): ► Press Snooze or any key ... the alarm is switched off and repeated after 5 minutes.

## Baby monitor

When the baby monitor is switched on, the stored (internal or external) destination number is called as soon as a defined noise level is exceeded in the vicinity of the handset. The alarm to an external number is cancelled after approximately 90 seconds.

You can answer the alarm using the **Two Way Talk** function. This function is used to switch the loudspeaker of the handset located in the baby's room on or off.

In baby monitor mode, incoming calls are only indicated on the display (**without ringtone**). The display backlight is reduced to 50%. Advisory tones are deactivated. All keys are locked, with the exception of the display keys and the ability to press the centre of the control key.

If you accept an incoming call, the baby monitor mode is suspended for the duration of the call, but the function **remains** activated. The baby monitor mode is not deactivated by switching the handset off and on again.

 The handset should be positioned 1 to 2 metres away from the baby. The microphone must point towards the baby.

Activating the function reduces the operating time of your handset. For that reason, place the handset in the charging cradle if necessary.

The baby monitor is activated 20 seconds after switching on.

The answer machine for the destination number must be switched off.

After switching on:

- ▶ Test sensitivity.
- ▶ Test the connection, if the alarm is being forwarded to an external number.

## Activating and setting the baby monitor

▶  ... use  to select  Additional Features ▶ OK ▶  Baby Monitor ▶ OK ... then

Baby Monitor activated

Switch on/off:


▶ **Activation:** ... use  to select On or Off

Enter destination:

▶  Send alarm to ▶ ... use  to select External or Internal

External: ▶  Number ▶ ... use  to select number or select a number from the directory: ▶ 

Internal: ▶  Handset ▶ Change ▶ ... use  to select the handset ▶ OK



Activate/deactivate two-way talk:

▶  Two Way Talk ▶ ... use  to select On or Off

Set microphone sensitivity:

▶  Sensitivity ▶ ... use  to select High or Low

Save settings: ▶ Save

The destination number is displayed in idle display when the baby monitor is activated.

## Deactivate baby monitor / cancel alarm

Deactivate the baby monitor: ► In idle status press the display key **OFF**

Cancel the alarm: ► Press the End call key  during an alarm

## Deactivate the baby monitor remotely



The alarm is forwarded to an external destination number.

The receiving phone supports tone dialling.

► Accept alarm call ► Press keys  

The baby monitor is deactivated and the handset is in idle status. The baby monitor settings on the handset (e.g. no ringtone) will remain activated until you press the display key **OFF**.

Reactivate baby monitor with the same number: ► ...**Activation** to switch back on (→ p. 30) ► **Save**

# Protection against unwanted calls

## Time control for external calls



Date and time have been set.

Enter a time period during which the handset should suspend ringing to indicate external calls e.g. during the night.

- ▶ ... use to select **Settings** ▶ **OK** ▶ **Audio** **Settings** ▶ **OK** ▶ **Ringtones (Handset)** ▶ **OK** ▶ **Time Control** ▶ **OK** ▶ ... then
- Switch on/off: ▶ use to select **On** or **Off**
- Enter time: ▶ use to switch between **Suspend ring. from:** and **Suspend ring. until:** ▶ ... use to enter start and end in 4-digit format
- Save: ▶ **Save**

Example

Time Control	
<b>For external calls:</b>	
On	
Suspend ring. from:	22:00
Suspend ring. until:	07:00
Back	Save



The time control only applies to the handset for which the setting is configured.

The telephone will continue to ring for numbers that have been assigned to a VIP group in the directory.

## Protection from anonymous callers

The handset will not ring if callers' numbers are not revealed. This setting can be applied to only one or to all registered handsets.

### For one handset

- ▶ ... use to select **Settings** ▶ **OK** ▶ **Audio Settings** ▶ **OK** ▶ **Ringtones (Handset)** ▶ **OK** ▶ **Anon. Calls Silent** ▶ **Edit** ( = on) ... the call is only signalled on the display

### For all handsets

(only on some Gigaset bases)

- ▶ ... use to select **Settings** ▶ **OK** ▶ **Telephony** ▶ **OK** ▶ **Anonymous Calls** ▶ **Edit** ( = on) ▶ ... use to select **Protection Mode:**

**No Protection** Anonymous calls are indicated in the same way as identified numbers

**Silent Call** The telephone will not ring and the incoming call will only appear in the display.

**Block Call** The telephone will not ring and the incoming call will not appear in the display. The caller will hear the busy tone.

Save settings: ▶ **Save**

## Black list

(only on some Gigaset bases:  [www.gigaset.com/compatibility](http://www.gigaset.com/compatibility))

When the black list function is activated, calls from black list numbers are not indicated or are only indicated in the display. These settings apply to all registered handsets.

### Displaying/editing the black list

►  ... use  to select  **Settings** ► **OK** ►  **Telephony** ► **OK** ►  **Black List** ► **Edit** ► **Blocked Numbers** ► **OK** ... the list of blocked numbers is displayed ... possible options:

Create an entry: ► **New** ► ... use  to enter a number ► **Save**

Delete an entry: ► ... use  to select an entry ► **Delete** ... the entry is deleted

### Transferring a number from a call list to the black list

►  ... use  to select  **Call Lists** ► **OK** ► ... use  to select **Accepted calls/ Missed calls** ► **OK** ► ... use  to select entry ► **Options** ► **Copy to Blacklist** ► **OK**

### Setting the protection mode

►  ... use  to select  **Settings** ► **OK** ►  **Telephony** ► **OK** ►  **Black List** ► **Edit** ►  **Protection Mode** ► **OK** ► ... use  to select desired protection:

**No Protection** All calls are indicated, including from callers whose numbers are on the black list.

**Silent Call** The telephone will not ring and the incoming call will only appear in the display.

**Block Call** The telephone will not ring and the incoming call will not appear in the display. The caller will hear the busy tone.

Save settings: ► **Save**

### Switch off ringtone when in charging cradle

The handset will not ring when placed in the charging cradle. The call is only indicated on the display.

►  ... use  to select  **Settings** ► **OK** ►  **Audio Settings** ► **OK** ►  **Ringtones (Handset)** ► **OK** ► **Silent Charging** ► **Change** ( = ringtone is switched off when in charging cradle)

## Resource Directory

Sounds for ringtones and images that can be used as caller pictures (CLIP pictures) or as a screensaver are saved in the handset's resource directory. A range of monophonic and polyphonic sounds and pictures have been pre-set but further images and sounds can be downloaded using a PC ( Gigaset QuickSync).

### Media types:

Type	Format
<b>Sound</b>	Ringtones Monophonic Polyphonic Imported sounds
<b>Picture</b>	Internal Internal Internal WMA, MP3, WAV
	BMP, JPG, GIF 240 x 172 pixels 240 x 320 pixels

If insufficient memory is available, you must delete one or more pictures or sounds before others can be saved.

### Manage CLIP pictures/sounds

- ▶  ... use  to select  Additional Features ▶ OK ▶  Resource Directory ▶ OK  
... possible options:
  - View CLIP-picture: ▶  Caller Pictures ▶ OK ▶ ... use  to select picture ▶ View ... the selected picture is displayed
  - Play sound: ▶  Sounds ▶ OK ▶ ... use  to select sound ... the selected sound is played
  - Set volume: ▶ Options ▶ Volume ▶ OK ▶ ... use  to select volume ▶ Save
- Rename picture/sound:
  - ▶  Select Caller Pictures / Sounds ▶ OK ▶ ... use  to select sound/image ▶ Options ▶ Rename ▶ ... use  to delete name, use  to enter new name ▶ Save ... the entry is saved with the new name
- Delete picture/sound:
  - ▶  Select Caller Pictures / Sounds ▶ OK ▶ ... use  to select sound/picture ▶ Options ▶ Delete entry ... the selected entry is deleted



The relevant options are not available if a picture/sound cannot be deleted.

### Check memory

Display the available memory for screensavers and CLIP-pictures.

- ▶  ... use  to select  Additional Features ▶ OK ▶  Resource Directory ▶ OK ▶  Capacity ▶ OK ... the percentage of available memory is displayed

## Additional functions using the PC interface



The Gigaset QuickSync program has been installed on the computer.

Free to download at ➔ [www.gigaset.com/quicksync](http://www.gigaset.com/quicksync)

QuickSync functions:

- Sync the handset's directory with Microsoft® Outlook®
  - Upload CLIP-pictures (.bmp) from the computer to the handset
  - Upload pictures (.bmp) as screensavers from the computer to the handset
  - Upload sounds (ringtone melodies) from the computer to the handset
  - Update firmware
  - Cloud synchronisation with Google™
- Connecting the handset with the computer via a USB data cable.



Connect the handset **directly** to the PC, **not** via a USB hub.

### Transferring data

- Launch the **Gigaset QuickSync** program on the computer.

The message **Data transfer in progress** is shown on the display during data transfer between the handset and PC. During this time, it is not possible to enter any data using the keypad and incoming calls are ignored.

### Carrying out a firmware update

- Connect the telephone and the PC using a **USB data cable** ► Launch **Gigaset QuickSync** ► Establish connection to the handset
- Start firmware update in **Gigaset QuickSync** ... Information about this can be found in **Gigaset QuickSync** help feature

The update process may take up to 10 minutes (not including download time).

The data are first downloaded from the online update server. The time required for this depends on Internet connection speed.

The display on your telephone is switched off and the Message key and the Talk key will flash.

Once the update is complete, your telephone will automatically restart.



The firmware can also be updated directly via the DECT radio link if the base/router supports this (➔ **Handset Update**).

### Procedure in the event of an error

If the update procedure fails or the telephone no longer functions properly after the update, repeat the update procedure:

- ▶ End the **Gigaset QuickSync** program on the PC ▶ Remove the USB data cable from the telephone ▶ Remove the battery ▶ Replace the battery
  - ▶ Carry out the firmware update again as described above
- If the update procedure fails more than once or it is no longer possible to connect to the PC, carry out the **Emergency Update**:
- ▶ End the **Gigaset QuickSync** program on the PC ▶ Remove the USB data cable from the telephone ▶ Remove the battery
  - ▶ Press and hold keys **[4]** and **[6]** at the same time with the forefinger and middle finger ▶ Replace the battery
  - ▶ Release keys **[4]** and **[6]** ... the Message key **[✉]** and the Talk key **[📞]** will flash alternately
  - ▶ Carry out the firmware update as described above



Always save pictures and sounds uploaded onto the handset on the PC, as they are deleted during an **Emergency Update**.

# Setting the handset

## Changing the language

- ▶  ... use  to select  Settings ▶ OK ▶  Language ▶ OK ▶ ... use  to select language ▶ Select ( = selected)

If the handset has been set to an incomprehensible language:

- ▶  Press the keys **9 5** slowly one after the other ▶ ... use  to select the correct language ▶ press the right display key

## Display and keypad

### Screensaver

A digital or analogue clock, Info Services and a range of pictures can be selected to be displayed as a screensaver when in idle status.

- ▶  ... use  to select  Settings ▶ OK ▶  Display & Keypad ▶ OK ▶  Screensaver ▶ Edit ( = on) ... then
  - Switch on/off: ▶ Activation: ... use  to select On or Off
  - Select screensaver: ▶  Selection ▶ ... use  to select a screensaver (Digital Clock / Analog Clock / Info Services / <Pictures> / Slideshow)
  - View screensaver: ▶ View
  - Save selection: ▶ Save

The screensaver is activated approx. 10 seconds after the display has changed to idle status.



All pictures from the **Screensaver** folder of the **Resource Directory** are available for selection.

### End screensaver

- ▶ Press the End call key  briefly ... the display changes to idle status

### Notes on displaying Info Services

(only on a Gigaset GO-Box 100 or other Gigaset-IP base)



**Info Services** are activated via the web configurator.

The telephone is connected to the Internet.



The type of info service available to your phone is set on the Internet on the Gigaset.net server.

If no information is currently available, the digital time (**Digital Clock**) is displayed instead until information is available again.

### Switching the information ticker on/off

(only on a Gigaset GO-Box 100 or other Gigaset-IP base)

The text information from the Internet that is set for the screensaver **Info Services** can be displayed as a scrolling message in idle status.

- ▶  ... use  to select  **Settings** ▶ **OK** ▶  **Display & Keypad** ▶ **OK** ▶  **Info Ticker** ▶ **Edit** ( = on)

The ticker starts as soon as the telephone changes to idle status. If a message is shown in the display, the information ticker is not displayed.

---

### Large font

Show text and icons in call lists and in the directory in a larger size in order to improve legibility. Only one entry is shown in the display and names are abbreviated if necessary.

- ▶  ... use  to select  **Settings** ▶ **OK** ▶  **Display & Keypad** ▶ **OK** ▶  **Large Font** ▶ **Change** ( = on)

---

### Colour scheme

The display may appear in a range of colour combinations.

- ▶  ... use  to select  **Settings** ▶ **OK** ▶  **Display & Keypad** ▶ **OK** ▶  **Colour Schemes** ▶ **OK** ▶ ... use  to select the desired colour scheme ▶ **Select** ( = selected)

---

### Display backlight

The display backlight always illuminates when the handset is taken out of the base station/charging cradle or when a key is pressed. Any **digit keys** that are pressed appear on the display for pre-dialling.

Switch the display backlight on/off when in idle status:

- ▶  ... use  to select  **Settings** ▶ **OK** ▶  **Display & Keypad** ▶ **OK** ▶  **Display Backlight** ▶ **OK** ... then

Backlight when in the charging cradle:

- ▶ **In Charger:** ... use  to select **On** or **Off**

Backlight when not in the charging cradle:

- ▶  **Out of Charger** ▶ ... use  to select **On** or **Off**

Save selection: ▶ **Save**



The handset's standby time may be significantly reduced if the display backlight is switched on.

## Keypad illumination

You can set the brightness of keypad illumination in 5 increments.

- ▶  ▶ ... use  to select  **Settings** ▶ **OK** ▶  **Display & Keypad** ▶ **OK** ▶  **Key Illumination** ▶ **OK** ▶ ... use  to select **Brightness (1 - 5)** ▶ **Save**

## Activating/deactivating automatic keypad lock

Automatically lock the keypad when the handset has been in idle status for around 15 seconds.

- ▶  ▶ ... use  to select  **Settings** ▶ **OK** ▶  **Display & Keypad** ▶ **OK** ▶  **Auto Keypadlock** ▶ **Change**  = **on**

## Activating/deactivating Auto Answer

When set to Auto Answer, the handset accepts an incoming call as soon as it is removed from the charging cradle.

- ▶  ▶ ... use  to select  **Settings** ▶ **OK** ▶  **Telephony** ▶ **OK** ▶  **Auto Answer** ▶ **Change**  = **on**

Regardless of the **Auto Answer** setting, the connection ends as soon as you place the handset back in the charging cradle. exception: Press and hold the handsfree key  for a further 2 seconds while placing the handset in the charging cradle.

## Changing the earpiece and handsfree volume

You can set the volume of the earpiece and speaker at 5 levels independently of each other.

### During a conversation

- ▶  **Handset Volume** ▶ ... use  to select volume ▶ **Save** ... the setting is saved

 Without saving, the setting is automatically saved after around 3 seconds.

### In idle status

- ▶  ▶ ... use  to select  **Settings** ▶ **OK** ▶  **Audio Settings** ▶ **OK** ▶  **Handset Volume** ▶ **OK** ... then

For the earpiece: ▶ **Earpiece:** ... use  to set the volume

For the speaker: ▶  **Speaker** ▶ ... use  to set the volume

Save settings: ▶ **Save**

## Earpiece and handsfree profile

Select a profile for the **earpiece** and **handsfree mode** in order to adapt the telephone as much as possible to the surroundings. Check which is the most comfortable profile for you and your caller.

- ▶  ... use  to select  **Settings** ▶ **OK** ▶  **Audio Settings** ▶ **OK** ▶   **Acoustic Profiles** ▶   **Earpiece Profiles / Handsfree Profiles** ▶ **OK** ▶ ... use  to select profile ▶ **Select** ( = selected)

**Earpiece Profiles:** High or Low (default setting)

**Handsfree Profiles:** Profile 1 (default setting) ... Profile 4

---

## Ringtones

### Ringtone volume

- ▶  ... use  to select  **Settings** ▶ **OK** ▶  **Audio Settings** ▶ **OK** ▶  **Ringtones (Handset)** ▶ **OK** ▶  **Volume** ▶ **OK** ▶ ... use  to select **For internal calls and alarms** or **External Calls** ▶ ... use  to set volume in 5 increments or in crescendo mode (increasing volume) ▶ **Save**

Example



### Ringtone melody

Set a variety of ringtones for internal and external calls for every available send/receive connection of the telephone (**Landline**, **IP1**) or set the same ringtone for **All calls**.

- ▶  ... use  to select  **Settings** ▶ **OK** ▶  **Audio Settings** ▶ **OK** ▶  **Ringtones (Handset)** ▶ **OK** ▶  **Melodies** ▶ **OK** ▶ ... use  to select the connection ▶ ... use  to select the ringtone/melody in each case ▶ **Save**

---

## Switching the ringtone on/off

### Switching the ringtone off permanently

- ▶ Press and **hold** the key  ... the following icon appears in the status bar 

### Switching the ringtone on permanently

- ▶ Press and **hold** the key 

### Switching the ringtone off for the current call

- ▶ **Silence** or press the End call key 

## Switching the alert tone (beep) on/off

Switch on an alert tone (beep) instead of the ringtone:

- ▶ Press and **hold** the star key  ▶ press **Beep** within 3 seconds ... the following icon appears in the status bar 

Switching off the alert tone: ▶ Press and **hold** the star key 

## Switching advisory tones on/off

The handset notifies acoustically about different activities and statuses. These advisory tones can be switched on/off independently of each other.

- ▶  ▶ ... use  to select  **Settings** ▶ **OK** ▶  **Audio Settings** ▶ **OK** ▶  **Advisory Tones** ▶ **OK** ... then

Tone when keys are pressed:

- ▶ **Key Tones:** ... use  to select **On** or **Off**

Confirmation/error tone after making entries, advisory tone when a new message has been received:

- ▶  **Confirmation** ▶ ... use  to select **On** or **Off**

Warning tone when there are fewer than 10 minutes of talktime remaining (every 60 seconds):

- ▶  **Battery** ▶ ... use  to select **On** or **Off**

Warning tone when the handset is moved out of range of the base station:

- ▶  **Out of Range:** ... use  to select **On** or **Off**

Save settings: ▶ **Save**



There is no battery warning when the baby monitor is switched on.

## Fast access to numbers and functions

**Number keys:** It is possible to assign a **number from the directory** to the keys  and  to .

**Display keys:** The left and right display keys have a **function** preset by default, but the keys can be re-assigned.

You can then dial the number or start the function by simply pressing a key.

## Assigning a number to digit keys (quick dial)



A number has not been assigned to the digit key.

- ▶ Press and **hold** the digit key
- or
- ▶ **Briefly** press the digit key ▶ Press the display key **QuickDial**  
The directory opens.
- ▶ ... use to select an entry ▶ **OK** ▶ ... use to select a number if necessary ▶ **OK** ...  
the entry is saved to the digit key

If the entry in the directory is deleted later, this will not affect the assignment of the digit key.

### Dialling a number

- ▶ Press and **hold** the digit key ... the number is dialled immediately
- or
- ▶ **Briefly** press the digit key ... the number/name (possibly in abbreviated form) is shown on the left display key ▶ ... press the display key ... the number is dialled

### Changing the digit key assignment

- ▶ **Briefly** press the digit key ▶ **Change** ... the directory is opened ... possible options:  
Change the assignment:

- ▶ ... use to select an entry ▶ **OK** ▶ ... select a number if required ▶ **OK**

Delete the assignment:

- ▶ **Clear Key**

## Assigning display keys, changing assignments

- ▶ Press and **hold** the left or right display key in idle status ... the list of possible key assignments is opened ▶ ... use to select function ▶ **OK** ... possible options:

<b>Baby Monitor</b>	Set and activate/deactivate baby monitor
<b>Alarm Clock</b>	Set and activate/deactivate the alarm clock
<b>Calendar</b>	Open calendar
<b>One Touch Call</b>	Set up one touch call
<b>Redial</b>	Show redial list
<b>eMail</b>	Open the e-mail submenu for receiving and reading e-mail notifications
<b>More Functions...</b>	▶ <b>OK</b> ▶ ... use  to select other function
<b>Send Connections</b>	Set send connection for the next call

Line Selection	Open the connection selection menu
Call Lists	Show call list
Withhold Number	Withhold phone number identification for next call
Call Divert	Activate/deactivate Call Divert
eMail	Open the e-mail submenu for receiving and reading e-mail notifications
Info Centre	Start the Info Centre and open the list of available Info Services – go online.
Net Directories	Display the list of network directories



The availability of options depends on the base.

### Starting a function

With the telephone in idle status: ► Briefly press ... the assigned function is executed

---

## Changing the name of a connection (line)

(only on a CAT-iq router)

- [ ] ► ... use [ ] to select [ ] Settings ► OK ► [ ] Telephony ► OK ► [ ] Connections ► OK ... all available connections (lines) are displayed ► ... use [ ] to select connection ► OK ► [ ] Connection Name ► OK ► ... use [ ] to change the name of the connection ► Save

---

## Assigning handsets to a connection (line)

(only on a CAT-iq router)

Multiple handsets can be assigned to a connection. Incoming calls to the number designated to a connection will be forwarded to all handsets assigned to the connection.

- [ ] ► ... use [ ] to select [ ] Settings ► OK ► [ ] Telephony ► OK ► [ ] Connections ► OK ► ... use [ ] to select connection ► OK ► [ ] Assigned Handsets ... all registered handsets are displayed ► ... use [ ] to select handset ► Change ( [ ] = handset is assigned)

---

## Permit/prevent multiple calls

(only on a CAT-iq router)

If the function is activated, multiple calls can be made in parallel.

- [ ] ► ... use [ ] to select [ ] Settings ► OK ► [ ] Telephony ► OK ► [ ] Connections ► OK ► ... use [ ] to select connection ► OK ► [ ] Multiple Calls ► Change ( [ ] = on)

## Permit/prevent internal listening in

(only on a CAT-iq router)

If the function is enabled, an internal party can listen in to an external call and take part in the conversation (conference).

-  ... use  to select  Settings ► OK ►  Telephony ► OK ►   Connections ► OK ► ... use  to select connection ► OK ►   Listening In ► OK ►  Change ( = on)

---

## Handset update

The handset supports firmware updating via the DECT radio link to the base/router (SUOTA = Software Update Over The Air).

-  The base/router to which the handset is registered must also support this function  
(→ [www.gigaset.com/compatibility](http://www.gigaset.com/compatibility))

If your base/router does not support this function, you can also update the firmware via a USB cable and **Gigaset Quick Sync**.

If new firmware is available for the handset a message to this effect will be displayed.

- Start the firmware update with **Yes**.

Start the firmware update manually:

-  ... use  to select  Settings ► OK ►  System ► OK ►   Handset Update ► OK ►  Update ► OK ► OK ... if there is new firmware, the update will start



The update process may take up to 30 minutes. During this time, only restricted handset use is available.

---

## Resetting the handset to the default settings

Reset any individual settings and changes that you have made.

-  ... use  to select  Settings ► OK ►  System ► OK ►   Handset Reset ► OK ► Yes ... the handset's settings are reset

The following settings are **not** affected by a reset

- Registration of the handset to the base station
- Date and time
- Directory entries and call lists

# Appendix

---

## Service (Customer Care)

Step by step towards your solution with Gigaset Customer Care  
[www.gigaset.com/service](http://www.gigaset.com/service)



### Visit our Customer Care pages

Here you will find:

- Frequently asked questions
- Free software and user manual downloads
- Compatibility checks



### Contact our Customer Care team

Couldn't find a solution in the FAQs section?  
 We are happy to help...

#### ... online:

via our contact form on the customer service page

#### ... by telephone:

##### **Customer Service Switzerland: 0848 212 000**

(0.09 Fr. per minute from the Swiss phone network. For calls from mobile phone networks, other prices may apply)

Please have your proof of purchase ready when calling.

Please note that if the Gigaset product is not sold by authorised dealers in the national territory the product may not be fully compatible with the national telephone network. It is clearly specified on the box near the CE mark for which country/countries the equipment has been developed.

If the equipment is used in a manner inconsistent with this advice or with the instructions of the manual and on the product itself, this may have implications on the conditions for warranty or guarantee claims (repair or exchange of product).

In order to make use of the warranty, the product purchaser is asked to submit a receipt which proves the date of purchase (date from which the warranty period starts) and the type of goods that have been purchased.

---

## Manufacturer's advice

---

### Authorisation

This device is intended for use worldwide. Use outside the European Economic Area (with the exception of Switzerland) is subject to national approval.

Country-specific requirements have been taken into consideration.

Hereby, Gigaset Communications GmbH declares that the radio equipment type Gigaset CL660HX is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:  
[www.gigaset.com/docs](http://www.gigaset.com/docs)

This declaration could also be available in the "International Declarations of Conformity" or "European Declarations of Conformity" files.

Therefore please check all of these files.

## Environment

---

### Environmental management system



Gigaset Communications GmbH is certified pursuant to the international standards ISO 14001 and ISO 9001.

**ISO 14001 (Environment):** Certified since September 2007 by TÜV SÜD Management Service GmbH.

**ISO 9001 (Quality):** Certified since 17/02/1994 by TÜV SÜD Management Service GmbH.

---

### Disposal

Batteries should not be disposed of in general household waste. Observe the local waste disposal regulations, details of which can be obtained from your local authority.

### Information about disposal



At the end of its service life, this product must not be disposed of with normal household waste, but must be handed in at the place of purchase or at a collection point for recycling electrical and electronic devices in accordance with the ordinance governing the return, acceptance and disposal of electrical and electronic equipment (VREG).

The materials can be recycled according to their identification. By reusing and recycling materials along with other methods of recycling used equipment, you can make an important contribution to protecting the environment.

---

### Care

Wipe the device with a **damp** cloth or an antistatic cloth. Do not use solvents or microfibre cloths.

**Never** use a dry cloth; this can cause static.

In rare cases, contact with chemical substances can cause changes to the device's exterior. Due to the wide variety of chemical products available on the market, it was not possible to test all substances.

Impairments in high-gloss finishes can be carefully removed using display polishes for mobile phones.

---

### Contact with liquid



If the device comes into contact with liquid:

- 1 **Disconnect the power supply.**
- 2 **Remove the batteries and leave the battery compartment open.**
- 3 Allow the liquid to drain from the device.
- 4 Pat all parts dry.
- 5 Place the device in a dry, warm place **for at least 72 hours (not** in a microwave, oven etc.) with the battery compartment open and the keypad facing down (if applicable).
- 6 **Do not switch on the device again until it is completely dry.**

When it has fully dried out, you will normally be able to use it again.

# Technical data

## Batteries

Technology:	2 x AAA NiMH
Voltage:	1.2 V
Capacity:	750 mAh

## Handset operating times/charging times

The operating time of your Gigaset depends on the capacity of the battery, its age and the way it is used. (All times are maximum possible times.)

Standby time (hours)	280 / 170 *
Talktime (hours)	14
Operating time with 1.5 hours of calls per day (hours)	130 / 95 *
Charging time in charging cradle (hours)	9.5

\* No Radiation deactivated/activated, without display backlight in idle status

## Power consumption of the handset in the charging cradle

When charging:	approx. 4.5 W
To maintain the charge status:	approx. 0.30 W

## General specifications

DECT standard	Supported
CAT-iq standard	Certified in accordance with standard CAT-iq 2.0 with HD Voice <a href="http://www.dect.org/cat-iq-certification.aspx">www.dect.org/cat-iq-certification.aspx</a>
GAP standard	Supported
No. of channels	60 duplex channels
Radio frequency range	1880-1900 MHz
Duplex mode	Time division multiplexing, 10 ms frame length
Repetition frequency of the transmission pulse	100 Hz
Duration of the transmission pulse	370 µs
Channel grid	1728 kHz
Bit rate	1152 kbit/s
Modulation	GFSK
Language code	32 kbit/s
Transmission power	10 mW average power per channel, 250 mW pulse power
Range	Up to 50 m indoors, up to 300 m outdoors
Environmental conditions for operation	+5 °C to +45 °C; 20% to 75% relative humidity

## Character charts

### Standard characters

Press the relevant key the number of times indicated.

	1x	2x	3x	4x	5x	6x	7x	8x	9x	10x
1	1									
2	a	b	c	2	ä	á	à	â	ã	ç
3	d	e	f	3	ë	é	è	ê		
4	g	h	i	4	ï	í	ì	î		
5	j	k	l	5						
6	m	n	o	6	ö	ñ	ó	ò	ô	õ
7	p	q	r	s	7	ß				
8	t	u	v	8	ü	ú	ù	ú		
9	w	x	y	z	9	ÿ	ý	æ	ø	ã
0	<sup>1)</sup> [ ]	.	,	?	!		<sup>2)</sup> 0			

1) Space

2) Line break

# Display icons

The following icons are displayed depending on the settings and the operating status of your telephone.

## Icons in the status bar

Icon	Meaning
	Signal strength (No Radiation off) 1% - 100% white, if Maximum Range on; green, if Maximum Range off
	Red: no connection to the base station
	No Radiation activated: white, if Maximum Range on; green, if Maximum Range off
	Answer machine activated indicator flashes: Answer machine is recording a message or is being operated by another internal participant
	Ringtone switched off
	"Beep" ringtone activated

Icon	Meaning
	Keypad lock activated
	Battery charge status: White: between 11% and 100% charged Red: less than 11% charged
	Flashes red: battery almost empty (approx. 5 minutes of talktime left)
	Battery is charging (current charge status): 0% - 100%

## Display key icons

Icon	Meaning
	Last number redial
	Delete text

Icon	Meaning
	Open the directory
	Copy number to the directory
	Divert a call to answer machine

## Display icons to indicate ...

Icon	Meaning
	External call
	Internal call
	Establishing a call (outgoing call)
	Connection established
	No connection established/ connection terminated

Icon	Meaning
	Reminder for appointment
	Reminder for anniversary
	Alarm call
	Countdown timer
	Answer machine is recording

## Display icons

### Other display icons

Icon	Meaning
	Alarm clock is activated, display with alarm time
	Action complete (green)
	Action failed (red)

Icon	Meaning
	Information
	(Security) prompt
	Please wait ...

# Index

<b>A</b>	
Advisory tones .....	41
Alarm .....	29
Alarm clock .....	29
switch on/off .....	29
Alert tone (beep) .....	41
Anniversary, see Appointment	
Answer .....	39
Answer machine .....	19
calling back a caller .....	25
Appointment	
display missed .....	28
missed .....	28
notification .....	27
setting .....	27
Assigning number key .....	41
Authorisation .....	45
Auto	
answer .....	39
Automatic	
answer .....	39
<b>B</b>	
Baby monitor .....	30
activation .....	30
deactivation .....	31
Battery	
charging .....	8
charging status .....	49
inserting .....	8
Beep (alert tone) .....	41
Best base station .....	9
Black list .....	33
Broken display .....	6
<b>C</b>	
Calendar .....	27
Call	
external .....	16
Call block .....	33
Call list	
copying a number to the directory .....	25
delete .....	25
delete an entry .....	25
dialling .....	17
entry .....	25
opening .....	25
Call lists .....	25
Call protection .....	32
Call, anonymous	
protection from .....	32
Calling	
external .....	16
Cancel the alarm (baby monitor) .....	31
Care .....	46
Care of the device .....	46
Changing	
display language .....	37
earpiece volume .....	39
handsfree volume .....	39
Character charts .....	48
Charge status of the batteries .....	49
Charging cradle (handset)	
connecting .....	7
Charging time of handset .....	47
CLIP-picture	
view in Resource Directory .....	34
Colour scheme .....	38
Connecting the USB data cable .....	11
Connection	
assigning handset .....	43
changing name .....	43
Contact with liquid .....	46
Contents of the package .....	7
Control key .....	3, 12
Correcting incorrect entries .....	15
Customer Care .....	45
<b>D</b>	
Dialling	
from the call list .....	17
from the directory .....	16
from the redial list .....	16
using quick dial .....	42
Directory .....	20
copying numbers .....	22
dialling numbers .....	16
entry .....	20
memory .....	21
opening .....	20
order of entries .....	21
saving an entry .....	20
searching .....	21
selecting an entry .....	21
sending entry/list to handset .....	23
sending to handset .....	23
Display	
backlight .....	38
broken .....	6
changing display language .....	37
colour scheme .....	38
directory memory .....	21
missed appointment/anniversary .....	28
network mailbox message .....	24
screensaver .....	37
setting .....	37
Display icons .....	49
Display keys .....	3, 13
assigning .....	41
icons .....	49
Disposal .....	46

---

<b>E</b>	
Earpiece profile . . . . .	40
Earpiece volume . . . . .	18
Emergency numbers	
not possible . . . . .	6
End call key . . . . .	3, 16
Entering numbers . . . . .	15
Entering special characters . . . . .	15
Entering text . . . . .	15
Entering umlauts . . . . .	15
Environment . . . . .	46
<b>F</b>	
Firmware update . . . . .	44
Firmware updates . . . . .	35
<b>G</b>	
Garantie . . . . .	45
Getting started . . . . .	7
Gigaset QuickSync . . . . .	23
<b>H</b>	
Handset	
advisory tones . . . . .	41
assigning connection . . . . .	43
automatic keypad lock . . . . .	39
changing the settings . . . . .	37
colour scheme . . . . .	38
connecting the charging cradle . . . . .	7
display backlight . . . . .	38
display language . . . . .	37
earpiece volume . . . . .	18, 39
handsfree volume . . . . .	39
idle status . . . . .	14
keypad illumination . . . . .	39
large font . . . . .	38
muting . . . . .	18
overview . . . . .	3
registering . . . . .	9
restoring to default setting . . . . .	41
set up . . . . .	8
speaker volume . . . . .	18
switch on/off . . . . .	12
update . . . . .	44
use as a baby monitor . . . . .	30
Handsfree key . . . . .	18
Handsfree mode . . . . .	18
Handsfree profile . . . . .	40
Hash key . . . . .	3
Headset connection . . . . .	3, 8
Headset socket . . . . .	11
Hearing aids . . . . .	6
<b>I</b>	
Icons	
alarm clock . . . . .	29
displaying new messages . . . . .	24
indications . . . . .	49
on display keys . . . . .	49
status bar . . . . .	49
Idle status	
returning to . . . . .	14
Illumination, keypad . . . . .	39
Indications, icons . . . . .	49
Internal listening in . . . . .	44
<b>K</b>	
Key 1 (fast access) . . . . .	3
Key, assigning . . . . .	41
Keypad illumination . . . . .	39
Keypad lock, automatic . . . . .	39
Keys	
control key . . . . .	3, 12
display keys . . . . .	3, 13
end call key . . . . .	3, 16
handsfree . . . . .	18
hash key . . . . .	3
menu . . . . .	12
message key . . . . .	3
on/off key . . . . .	3
recall key . . . . .	3
star key . . . . .	3
talk key . . . . .	3
<b>L</b>	
Language	
display . . . . .	9
Language, display . . . . .	37
Large font . . . . .	38
Line . . . . .	43
Liquid . . . . .	46
Lock/unlock the keypad . . . . .	12
Lower/upper case . . . . .	15
<b>M</b>	
Making calls	
external . . . . .	16
Medical equipment . . . . .	6
Melody	
ringtone for internal/external calls . . . . .	40
Memory in the directory . . . . .	21
Memory, resource directory . . . . .	34
Menu key . . . . .	12
Message key . . . . .	3
Message lists . . . . .	24
Microphone	
switch on/off . . . . .	18
Missed anniversaries/appointments . . . . .	28
Multiple calls . . . . .	43
Muting the handset . . . . .	18

---

---

<b>N</b>	
Number	
copying to the directory	22
saving in the directory	20
<b>O</b>	
On/off key	3
Operating time of handset	47
Overview	
handset	3
<b>P</b>	
PC Interface	35
Picture	
as CLIP image	34
as screensaver	34
delete	34
formats	34
rename	34
Power adapter	6
Protection from calls	
anonymous	32
black list	33
switch off ringtone when in charging cradle	33
time control	32
<b>Q</b>	
Quick dial	16
QuickSync	23, 35
<b>R</b>	
Recall key	3
Redial list	16
Registering (handset)	9
Resetting the handset to the default settings	44
Resource Directory	34, 41
memory	34
view CLIP picture	34
Ring delay	39
Ringtone	40
changing	40
melody for internal/external calls	40
switch off when in charging cradle	33
time control	32
volume	40
<b>S</b>	
Safety precautions	6
Screensaver	37
Searching in directory	21
Sending	
entire directory to handset	23
Service	45
Setting the date	10
Setting the time	10
Setting up	
handset	8
Show new messages	24
Signal strength	49
Signal tone, see Advisory tones	
Snooze mode (alarm)	29
Sound	
delete	34
formats	34
playback	34
rename	34
Sounds for ringtones	34
Speaker	18
Speaker volume	18
Star key	3
Status bar	
icons	49
SUOTA	44
Symbols, see Icons	49
<b>T</b>	
Talk key	3
Technical data	47
Telephone	
operating	12
Time control for external calls	32
<b>U</b>	
Update	35
Upper/lower case	15
USB connection socket	3
<b>V</b>	
Viewing network mailbox message	24
VIP group, classify directory entry	20
VIP ringtone	20
Volume	
earpiece	39
handset handsfree volume	39
handset speaker/earpiece volume	18
speaker	39
<b>W</b>	
Warning tone, see Advisory tones	

---

**Issued by**

Gigaset Communications GmbH

Frankenstr. 2a, D-46395 Bocholt

© Gigaset Communications GmbH 2016

Subject to availability.

All rights reserved. Rights of modification reserved.

[www.gigaset.com](http://www.gigaset.com)

Apple, the Apple logo and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Google, Android, Google Play and other brands are trademarks of Google Inc.