

HD-Phone Nyon setup

Make calls  
in HD sound  
quality



For inOne home offerings (Internet-Box):  
[www.swisscom.ch/hdphones-help](http://www.swisscom.ch/hdphones-help)  
0800 800 800

For inOne SME office offerings (Centro Business 2.0):  
[www.swisscom.ch/devices-help](http://www.swisscom.ch/devices-help)  
0800 055 055


Swisscom (Switzerland) Ltd.  
Contact Center  
CH-3050 Bern

[www.swisscom.ch](http://www.swisscom.ch)

**Start** You have received:



**1** You have one of these routers:



**2** Insert the batteries and close the compartment.



Installation overview



**3** Select your language.



**4** Take your HD-Phone and go to the place your router is installed.



**7** Information on the «Phonebook» and other functions can be found overleaf.




You have now set up your HD-Phone Nyon.

**6** Connect the adapter to the power socket of your choice.



We recommend you to charge your phone for at least 15 hours once you have set it up.


**5** Press the connection button on your router.




Wait for the HD-Phone to connect. If connecting your router didn't work, repeat steps 4–5.

KKD+JM (PMK-UID) SHP203 642\*2920\*1\*022 08/2017 EN

# Phonebook

Your Nyon HD-Phone gives you the option to save contacts under «MY CONTACTS» or «OUR CONTACTS». You can see in the menu at the icon  which phonebook is active.

You can simply **change to the other phonebook**:  
MENU >  > OK > OPTIONS > OUR CONTACTS / MY CONTACTS > OK

**MY CONTACTS** are saved locally, i.e. only on this handset.

## With inOne home (Internet-Box)

**OUR CONTACTS** are saved in the Internet-Box **central phonebook**. All the Swisscom HD-Phones you use at home can access the Internet-Box phonebook.

**Transfer your smartphone contacts** easily to the central phonebook:



Use the Swisscom Home app to transfer your smartphone contacts to the Internet-Box phonebook at the press of a button.

**Edit contacts** in your central phonebook:

You can edit the details under our contacts easily in the Internet-Box web portal at <http://internetbox>  
You can find additional information at [www.swisscom.ch/internetbox-phonebook](http://www.swisscom.ch/internetbox-phonebook)

**Before replacing the Internet-Box or a reset save the settings at:**

Internet-Box plus/standard:  
<http://internetbox> > Settings > Save configurations

Internet-Box light:  
<http://internetbox> > Advanced > Save current configuration

## With inOne SME office (Centro Business 2.0)

The **central subscriber directory** for your company is available automatically under **OUR CONTACTS**. You can maintain these contacts in the Customer Center at [www.swisscom.ch/login](http://www.swisscom.ch/login) > Business Telephony > My Telephone Numbers

The **call list** is automatically matched with the Customer Center.

# More functions

### Alarm clock

MENU > CLOCK > OK > SET ALARM > OK > set time > SAVE

### Program COMBOX®

MENU > NETWORK > OK > COMBOX > OK > COMBOX NUMBER > Enter your fixed network phone including prefix (e.g. 0860448008080).

You can access your COMBOX® by pressing the «1» key for a long time.

More info at [www.swisscom.ch](http://www.swisscom.ch) > Fixed network > COMBOX®







# Your HD-Phone: keys and display

## What does HD quality mean?










HD stands for High Definition. HD telephony means making calls in high sound quality. If both you and the person you are calling are using an HD-Phone over the Internet, your conversation will be in HD quality.



## Menu icons

-  Phonebook
-  Network (COMBOX®)
-  Calls
-  Clock (alarm)
-  Audio (melodies)
-  Settings

## Info icons

-  COMBOX® messages
-  Missed calls
-  Flashes: Phone not within range  
> Reduce the distance to the router.
-  Ecomode plus  
Ecomode plus is an environmentally friendly system that reduces electricity consumption and offers a variable reduction of transmission power. Transmission power is reduced by 100% as soon as Ecomode plus is activated.
-  Charge level display
-  Keypad is locked.  
> Press  key to unlock
-  Ringtones and notification alerts are switched off.  
> Press  key to switch on

# MultiLINE option

## With inOne home (Internet-Box)

You can define the settings for the incoming and outgoing numbers on the telephone:  
MENU > SETTINGS > OK > LINE SETTINGS > OK > INCOMING LINES / OUTGOING LINE > OK

Or at:

Internet-Box plus/standard:

<http://internetbox> > Telephony > Settings

Internet-Box light:

<http://internetbox> > Telephony > Handsets

For general information about MultiLINE go to [www.swisscom.ch/multiline](http://www.swisscom.ch/multiline)

## With inOne SME office (Centro Business 2.0)

Several phone numbers are available for inOne SME office M and L packages. You can pre-define the settings of incoming and outgoing numbers in the Customer Center ([www.swisscom.ch/login](http://www.swisscom.ch/login)) under the menu item «Business Telephony» and set them on your telephone.

You can find general information about inOne SME office offerings at [www.swisscom.ch/inonesme](http://www.swisscom.ch/inonesme)

# Safety instructions

### Please note

- > Protect your hearing: Ringtones and notification alerts are transmitted on the handset over the loudspeaker. Please do not hold the handset up to your ear when one of those functions is switched on – your hearing may otherwise be impaired.
- > In case of power outage, no emergency calls can be made with this handset. Please ensure that other calling options are available if needed.
- > Only use the handset in ambient temperatures from +5 to +40 degrees Celsius and protect it from direct sunlight
- > Do not use the handset/charger in potentially explosive environments (e.g. paint shops, petrol stations etc.).
- > Do not place the handset / charger in bathrooms or wet areas.
- > Only use the mains adaptor supplied.

### Impairment due to radio signals

- > The functioning of medical equipment may be impaired by the radio signals.
- > Hearing device wearers should note that when using the handset, radio signals in the hearing device might interfere and cause unpleasant buzzing sounds.

### Rechargeable batteries

- > Please use only NiMH AAA rechargeable batteries.
- > Do not use any other chargers, as the rechargeable batteries may otherwise be damaged.
- > Avoid batteries coming into contact with water or fire.
- > During charging batteries may heat up. This is normal and not dangerous.



Return your device to Swisscom.



Handset and charger compliance to EU Directive 2014/53/EU on radio systems and telecommunication equipment is certified by the CE symbol. The conformity declaration is available on the following website: [www.swisscom.ch/hdphones-help](http://www.swisscom.ch/hdphones-help)



For detailed information about your HD-Phone refer to: [www.swisscom.ch/hd-phones-help](http://www.swisscom.ch/hd-phones-help)