

Gigaset CL660HX

Quick and easy to set up

(Deutsch auf der Rückseite)

Start

You have received:


Gigaset CL660HX


Battery compartment cover


Battery


Gigaset CL660HX user guide


Power adapter


Charging cradle

1

You have one of these routers:


Internet-Box plus


Internet-Box 2


Centro Business 2.0



Internet-Box standard


Internet-Box light

Your router must be installed and switched on.

2

Insert the batteries and close the compartment.




Installation overview



3

Select your language.




4

Take your phone and go to the place your router is installed.



7

More information for Swisscom customers at www.swisscom.ch/hdphones-help



You have now set up your Gigaset CL660HX.

6

Connect the adapter to the power socket of your choice.



When you first set it up, we recommend fully charging the telephone until the display icon ⚡ is no longer visible.

5

Press the connection button on your router.



Wait for the phone to connect.
If the connection hasn't worked, repeat steps 4–5.
You can see the registration mode of the phone in the menu under
> Settings > Registration > Register Handset > OK