


Gigaset Maxwell C


Quick and easy to set up

(Deutsch auf der Rückseite)


Start You have received:



1 You have one of these routers:



2 Place the phone in the base and secure the tilt stand.



Installation overview



3 Connect the handset to the phone.



4 Connect the phone close to the router.



More information for Swisscom customers at www.swisscom.ch/hdphones-help




You have now set up your Gigaset Maxwell C. You can now plug the phone into any power socket of your choice.

Press the connection button on your router.



5 Select your language.



www.gigaset.com/service

KKD+JM (PMK-UID) 05/2018 EN