




Powerline

Connection Kit setup

Connecting two Powerline adapters



1

Plug the Powerline adapter **directly** into the wall power socket.



2

Plug the first Powerline adapter to your DSL router using the provided Ethernet cable.
«» and «» light up in green.

(It is possible that the LEDs blink. This is not an error.)




3

Plug the second Powerline adapter to your computer or your TV-Box.
«», «» and «» light up in green.

(If the computer or the TV-Box are not switched on, «» is not lit. It is possible that the LEDs blink. This is not an error.)

Displays (LED) and buttons



Ethernet connection



Everything is in order



Problem detected > Check that the cables are securely connected to the corresponding Powerline adapter.

Powerline connection



Excellent connection



Good connection



Low connection > Always connect the Powerline adapter directly to the wall electrical socket. If your wall electrical socket allows for multiple devices to be plugged in, make sure that the Powerline adapter is the only device plugged in.



no connection

Power



Power on



Energy saving mode > The Powerline adapters automatically switch off 15 minutes after the connected devices are powered off.



Out of service

Reset Button

With this button you can reset your Powerline adapter to its initial state. In order to do this, press the button for ca. two seconds and release. All LEDs light up briefly in orange.

Pairing Button

This button allows you to add additional Powerline adapters to your existing Powerline network.

Additional Powerline adapters

You can connect additional Powerline adapters (optional). In order to do so, your existing Powerline adapters must be on. If one of them is in energy saving mode, unplug it and replug it again. Wait until the green light turns on.


- 1 Plug the Powerline adapter into a power socket at the desired location.

- 2 Press approx. **15 seconds** the **Pairing button** of your **new Powerline adapter**, until all LEDs («», «» und «») light up in orange.




After a short while the LED indicating that your new adapter is in service «» will light up in green.

- 3 Press approx. **half a second** the **Pairing button** of one of your **already existing Powerline adapters**.




The service LED «» will start blinking in green.
Note: if it's not blinking, repeat this step.

- 4 Press approx. **half a second** the **Pairing button** of your **new Powerline adapter**.



The service LED «» will start blinking in green.
After a few seconds «» and «» light up in green.
Note: if it's not blinking, repeat this step.

- 5 Connect the Ethernet cable included in the package to your device.
(«», «» and «» light up in green. If the device is not on, «» does not light up.)



Note: you can connect additional Powerline adapters from Swisscom by proceeding exactly this way.

Important safety instructions

It is important to read and understand the following safety instructions before operating the Powerline adapter.

- › Do not exceed a 2250 Watt load on the adapter.
- › The Powerline adapter should only be used in a dry place.
- › Do not use the Powerline adapter in bathrooms.
- › The Powerline adapter must not be opened by unqualified personnel.
- › Do not try to repair the Powerline adapter yourself. You risk being electrocuted!
- › Under no circumstances should the Powerline adapter come into contact with water or other liquids.
- › Always use the supplied Ethernet cable to connect the Powerline adapter.
- › Do not insert any objects into the openings of the Powerline adapter.
- › To shut it off, unplug it from the socket.
- › Do not expose the Powerline adapter to direct sunlight.
- › Slots and openings on the housing are used for ventilation and must not be blocked or covered.
- › The Powerline adapter must not be set up next to a radiator.
- › The Powerline adapter should only be used in places where there is adequate ventilation.
- › Before cleaning the housing, disconnect the Powerline adapter from the mains. Never use water, thinner, benzene, alcohol or other strong detergents to clean the Powerline adapter as this may damage the housing. Use only a slightly damp cloth.
- › In the event of damage, disconnect the Powerline Adapter from the mains and return the Powerline adapter to the following address:

Swisscom (Switzerland) Ltd

Materialrücknahme

Postfach


4552 Derendingen

- › The following situations constitute damage:
 - › if the power cable or plug is damaged.
 - › if liquid is spilled on the Powerline adapter.
 - › if an object gets inside the Powerline adapter.
 - › if the Powerline adapter is exposed to rain or water.
 - › if the Powerline adapter does not work.
 - › if the Powerline adapter housing is damaged.

Swisscom (Schweiz) AG
Contact Center
CH-3050 Bern

www.swisscom.ch

SAP10042117 03/2011



Powerline-Netzwerk über bestehendes Stromnetz
Réseau Powerline par le réseau électrique existant
Rete Powerline tramite la rete elettrica esistente
Powerline network through existing electrical network