

Swisscom (Schweiz) AG
Contact Center
CH-3050 Bern

www.swisscom.ch

11/7/2012 YM_AP4641_UK_SW_D007

Universal Verbindungs-Kit einrichten
Installer le Kit de Connexion Universel
Installare il Kit di Connessione Universale
Install the Universal Connection Kit

S. 2

p. 6

p. 10

p. 14

UNO




Example installation

The **Universal Connection Kit wireless UNO** serves as a peripheral device to an existing Universal Connection Kit DUO. There are two situations in which the UNO device can be used:


Connecting to the Internet in an additional room

Thanks to the **Universal Connection Kit UNO**, you can connect up to **four devices** in another room to the Internet via Ethernet connection (for example the Swisscom TV-Box, a computer or a game console).



Increasing the range

As an additional option, the range of an existing Universal Connection Kit DUO can be increased by positioning the UNO between the two DUO devices of the Universal Connection Kit.




Setting up the Universal Connection Kit UNO (connecting to the Internet in an additional room)

Preparation: Connecting the new Connection Kit UNO

1. In the room in which the router is located, connect the UNO device to the mains and position it at a distance of **three metres** from the existing DUO device. Wait **two minutes until the device  flashes**.

 2 min.



2. **2.a** Press the **WPS button**  on the existing DUO device (next to the router) and then on the new UNO device a few seconds later **2.b**. The connection LEDs  start to flash and the devices connect automatically. This process will take five minutes. The connection has been established once the  lights up green.

 5 min.


Note: If the connection LED on the UNO device does not light up green within five minutes, please repeat step 2.

Setting up the Connection Kit UNO in the room of your choice

3. The UNO device can now be unplugged and placed next to the device that you would like to connect to the Internet (in this example, the TV-Box in another room).
4. Connect the device to the TV-Box using the Ethernet cable (yellow plug). The wireless connection will be established automatically. **This process will take up to five minutes**. Once the connection LED  lights up green, the connection has been established and the TV-Box is connected to the Internet.

 5 min.

Note: If the connection LED do not light up green within five minutes, please consult the chapter entitled «Troubleshooting» (page 17).



Setting up the Universal Connection Kit UNO (increasing the range)

Preparation: Connecting the Connection Kit UNO

Carry out steps **1.** – **2.** in the chapter entitled «Setting up the Universal Connection Kit UNO (connecting to the Internet in an additional room)» (page 15).

Placing a Connection Kit UNO in between the two devices


- 3.** The UNO device can now be unplugged and placed in between the DUO devices to be connected.
- 4.** The connection will be established automatically. **This process will take up to five minutes.** Once the connection LEDs on the UNO device and the DUO device to be connected (✓) light up green, the connection has been established.



Note: If the connection LEDs do not light up green within five minutes, please consult the chapter entitled «Troubleshooting» (page 17).

Optional: Connecting devices via Ethernet connection

- 5.** In addition to extending the range, the UNO device can also be used to connect devices via Ethernet connection, where necessary (for example the TV-Box). To do this, connect the device to the TV-Box using the Ethernet cable (yellow plug).



Troubleshooting

Power indicators



White: Device is switched on



Flashing white: Software update in progress > **please wait**



Off: Device is switched off or is not connected to the mains

Connection LED



Flashing green: Connection is being established > **please wait**



Green: Good connection



Red: Poor connection (for example jerky TV image)

The devices are connected to each other, but the distance between them is too large. Please carry out one of the following measures:

- > Reduce the distance between the devices by repositioning them.
- > Use another Connection Kit UNO to improve the strength of the connection (page 14).



Flashing red: No connection to the destination device

Please carry out one of the following measures:

- > Reduce the distance between the devices by repositioning them.
- > Connect the devices by pressing the WPS button (page 15, steps 1. – 2.).
- > Use another Connection Kit UNO to improve the strength of the connection (page 14).

Usage and safety instructions

- > Install the Connection Kit in accordance with these instructions.
- > Do not block any air vents.
- > Do not place the device directly on the ground.
- > Do not shut away the device in a cupboard or similar enclosure.
- > Position the device such that it is at least 15 cm from walls.
- > Do not position the device in the corner of a room.
- > Do not position the device near Bluetooth devices or a microwave oven.